

MyGica®

Android TV Box

Quad Core Enjoy TV Box

ATV1800E

Quick Start Guide



Thank you for purchasing the MYGICA ATV1800E

Your Satisfaction is the foundation of our success.

Follow this guide to setup your device.

Before using it, be sure to read the precautions contained in this User's Guide.

Keep the User's Guide in a safe place for future reference.


MyGica ATV1800E is the world's first GMS Google Certified 4K Quad Core Smart TV Box based on the ARM Cortex A9 AMLogic S802-B Quad Core Processor, paired with the Mali-450 Octa Core GPU and powered by the Android 4.4 KitKat Operating System.

You have full access to the Google Play Store to download all of your favorite android based applications, and install them right onto your MyGica ATV1800E. You also have access to our very own MyGica Store, which consists of pre-approved android apps for your MyGica ATV1800E. Alternatively, you can download android applications from third party stores and sources and install them directly using an external storage device and the preloaded AppInstaller App.

The MyGica ATV1800E comes with an Ethernet and WiFi connection, allowing you to connect to your home or office internet connection, as well many of your other devices all on the same network. This way, you can share content amongst your connected devices, such as videos, music and photos.


Product Overview

Panel Introduction




Connection

Place ATV1800E on a flat platform near the TV, and make sure nothing block the remote control signal.



Remote Controller



Packing List

Item	Description	Quantity
1	ATV1800E	1
2	Power Adaptor	1
3	Remote Control	1
4	A/V cable	1
5	RC Battery	2
6	Quick installation Guide	1
7	Warranty Card	1

Please be advice, battery might not be included due to air express.

After opening the box, please check carefully with the packing list, if any item is missing or damaged, please contact your dealer as soon as possible, or contact our customer service department.

First Time Usage

Part 1. - Power Up

1.1 - After power up, the TV will first show an animated "MyGica" logo during loading. When loading is finished, it will go to the Welcome screen.



1.2 - Welcome Screen - Follow the 4 steps to setup your ATV1800E



1.

Select Next with your remote.




2.

Select your language "English is default"



3.

Adjust your screen position to fit properly onto your Television




4.

Setup your WiFi or Ethernet Connection.

Refer to Part 3 of the manual located on pages 11-12 for more info on how to setup your internet connection.


Select "Finish" and you will now be taken to the Android Menu Selection Screen.

1.3 Android Launcher Menu Selection



You have 2 Android Launcher Menu to choose from.

For ease of use, we suggest to use the MyGica 4K HD Android Launcher. Highlight this option and select "Just Once". You will now be taken to the screen below.



1.4

The above screenshot is the Home Screen Menu of your ATV1800E. You will find an Icon labelled "Application" which will bring you to all of your Android Apps, as well as 8 Favorite App Icons to the right of this icon.

The Settings menu is also built into the Home Screen, you can access the Settings part by just using the IR Remote Control's Arrow Keys, moving them to the far left or right of the Home Screen.


1.5

Here is a list of some of the following Android Apps which come pre-installed on your Mygica ATV1800E:

- Google Play Store
- XBMC Gotham 13.2 Mygica Edition
- You Tube
- Mygica Store
- Netflix
- 4K Video Player
- And Many More

All of your Pre-Installed Android Apps can be found by just opening up the "Application" Icon, as shown on the screenshot on page 7.


Part 2. - How to change your Favorites Icons on the Home Screen



2.1

You can change the favorite applications on the Home Menu. To do so, using the IR Remote Control, move the cursor to the APP you want to change, press and hold the OK button and you will see the following screen.

Here we will use YouTube as an example.




2.2

You will now be taken to a list of all of your installed Android Apps, as shown in the screen shot above.

The APP with a "Star" in the top right corner of the App Icon is one of your already selected favorite applications located on the Home Screen Menu. Now choose the APP you want to switch as one of your new Favorites APP Icon on the Home Menu and press OK.

2.3


Here we will choose the Android App "AppInstaller".



2.4

Now you can see "AppInstaller" has become one of your favorite applications. You can repeat this process for each of the 8 Favorites icons that you want on your Home Screen.

Part 3 - How to change your Settings



3.1

The Settings menu is built into the Home Screen, you can access the Settings part by just using the IR Remote Control's Arrow Keys, moving them to the far left or right of the Home Screen.

The settings screenshot menu shown above, includes all the basic settings for the ATV1800E, if you want to access all other settings for the Android system, just click on "More Setting", this will take you

into the "Native Android Settings Menu"

Clicking on one of the highlighted icons as shown above, using the OK button on the IR remote control will open to that part of the settings menu that you want to edit.

3.2 WiFi Setup

3.2.1 The available WiFi networks in your area will be scanned when "ON" is selected.

3.2.2 Connect to the WiFi network that is available to you. If connecting to a secured WiFi network, the corresponding password will need to be entered in firstly. Or you will get "failed to connect" and need to re-enter the password.




3.3 Ethernet Setup

To connect your box via an Ethernet connection, you must use a RJ45 Ethernet Cable, connect it to the Ethernet port on the back of your ATV1800E and then connect the other end to your Router, Ethernet Switch or Powerline Adapter.


You must turn on the Ethernet connection by checking the Ethernet box and this will connect to a network automatically.

3.4 Display Resolution Setting

The Default resolution setting when you first turn on your ATV1800E is 720p



Using the remote, select "HDMI Output Mode Setting"



From here you can select your Video Resolution Output.


The Default resolution setting when you first turn on your ATV1800E is 720p

3.4.1 Output Mode

Here you can change the output mode from 480i, 480P, 720P, 1080P, 2K and 4K Resolution. Make sure the setting you choose is supported by your Television before switching the output mode.

3.5 Display Position Setting

Using the remote, move down and highlight the "Display Position" menu option. Select OK with the remote to open this setting menu.




Use the navigation keys (Left, Right, Up, Down) and OK buttons of the remote control to adjust your display position to fit your Television screen to your liking.




As the position of the screen may not display as a Full Screen onto your Television.

3.6 Language & input

Select the Language Icon to change your language settings




In here you can change to the Language of your choice, it is defaulted to "English (United States)"



3.7 Date & Time

Select the Date & Time Icon



In here you can Set your Date, Time, Time Zone, and Time Display Format

