

MyGica®
Seeing is Believing

ATV

1910

Digital TV box
powered by Android



User Manual

<http://www.mygica.com>

Quick Setup Guide



1. CVBS Port

2. USB Port

3. LAN Port

4. HDMI Port

5. DC Input

6. Wi-Fi Antenna



HDMI Cable



Power Adapter




Remote Control


After opening the box, please check carefully with the packing list. If any item is missing or damaged, please contact your dealer as soon as possible.

Connect Power and HDMI

Place ATV1910 on a flat platform near the TV, and make sure nothing block the remote control signal.





KR-41 Remote



Remote App

Do you want to use your Android Device as a Smart Remote Control? Scan the QR Barcode Below using your Android Device!




- | | | | | |
|-------------|---------------|--------------|-------------------------|---------------|
| 1. Power | 2. Menu | 3. Home | 4. Navigational buttons | 5. Play/Pause |
| 6. Vol - | 7. Vol + | 8. Air Mouse | 9. Return | 10. OK |
| 11. Page Up | 12. Page Down | 13. Stop | 14. Keyboard | |

- 1) Hold the Fn button to use the orange color keys.
- 2) Hold the shift button to use the 3rd keys on the top right corner (ex. :, ", <, >, ?)


First Time Usage


Part 1: Power Up

1.1. For first time power up, it will enter the setup wizard.




1.2. Select your language (Note: English is default).





1.3. Adjust your screen position to fit properly onto your television or monitor.



1.4. Setup your Wi-Fi or Ethernet connection.

1.5. Select “Finish”. You will be taken to Home Screen Selection.



1.6. The right screen shot is the MyGica Android 5.1 Home Screen.

“Application” will bring you to all of your Android Apps, as well as 8 Favorite App Icons to the right of this icon.


You can access the Settings menu by moving the cursor either to the left or right.

1.7. To change Favorite apps, just select the APP you want to change, then press and hold the OK button and you will see a list of all of the installed apps.

APP with a "star" are the one currently selected as favorite app. Now select the app you want to show on the home screen and press the OK button. The old favorite app will switch to the one you just select.




Part 2: How to change your settings



2.1. The settings menu includes all the basic settings for the ATV1910, if you want to access all other settings for the Android system, just select “More Setting”. This will take you into the native Android settings Menu.

2.2. Network Setup

In this menu you can setup Wi-Fi and Ethernet network.



2.2.1. Setup Wi-Fi

Select Wi-Fi then all the available Wi-Fi networks in your area will be scanned. Connect to the Wi-Fi network that is available to you. If connecting to a secured Wi-Fi network, the corresponding password will be required, or you will get “failed to connect” message and need to re-enter the password.

2.2.2. Setup Ethernet

First plugin your LAN cable then select Ethernet. Make sure Ethernet Device is turn on, and it will auto detect your network and gives you an ip address when connected.


2.3. Display Settings

In here you can change the screen resolution, screen position, screen rotation and Daydream (screen saver)

2.3.1. Screen resolution

In here you can select your video output resolution.

Make sure the setting you choose is supported by your television before switching the output mode.




2.3.2. Screen position

You can use Zoom in or Zoom out to adjust the screen position to fit your television screen to your liking.

2.3.3. Screen rotation


If some application request to change orientation, you can change in the setting.

You can choose from middle port, force land or original.



2.3.4. Daydream

In here you can setup screen saver when ATV1910 is inactive for a period of time. You can show a clock, a color changing screen, or photo.



2.4. Manage applications


Select Apps to manage all applications installed in the device.

First you can see all the downloaded applications.

You can see how many MB each applications are.

The next column shows all the system applications. Unlike downloaded applications, these applications cannot be uninstall.

The final column shows all the current running applications.



Select one of the application and click ok button will enable you to:

1. Open the application (some application auto runs in the background will not have this option.)


2. Uninstall the application (system application do not have this option), this will also delete user data and save game of the application.

3. Clear data: Delete any addition data this application has download or stored, some application or game will not work properly if download data is deleted.

4. Clear cache: Delete the temporary files stored by this application.
5. Clear defaults: Clear default setup.
6. Select show or not show notifications from this application.
7. Show permissions of this application.

2.5. Date & time


In this menu you can setup the Date, Time, Time Zone and Time Display Format.




2.6. Language

In this menu you can change the system language to the language of your choice.

(Note: Default language is English)






2.7. Factory data reset

In order to restore all settings to factory default settings, select reset, then select Factory data reset. In here you can erase all user data on the device and reset all settings to default settings.

Please take note, using this function will delete all user data and all user installed apks.



2.8. More Setting

You can access the original android settings in More setting.

3.0 App Market Places


You can find and install more applications by using the following market places already pre-installed on your MyGica.


- 1 - Google Play Store
- 2 - MyGica Store



4.0 KODI Media Center


KODI Media Center allows you to play and view most videos, music such as free podcasts from the internet, and all common digital media files from local and network storage media.






4.1 Playback local media files

Under Videos (same as Music and Pictures) there are 2 options, Files & Add-ons. To playback local media files, select 'Files' and enter Files interface, as shown in the picture:




Select 'Files' and if you have connect a USB storage device or a SD card, you will see "sda1" or "sdcard" (depends on the storage device you use). Select it and Kodi will list out all files within the storage device. You can then select a media file and start watching it.

4.2 Playback media from internet
KODI comes with some free internet
podcast channels, to view these
channels, goto Videos (or Music) and
select Add-ons.



Once you enter Add-ons, you will see
a list of different channels. These
channels are in alphabetical order,
browse through the list and select the
desire channels and start playback
the internet media.



Congratulations!

This completes the first time setup process of your brand new MyGica.

For technical support please visit our website <http://www.mygica.com>



<http://www.mygica.com>