

Burn firmware via USB burning tool


1. Install USB burning tool:

Download from the link below and install it on your PC: USB_Burning_Tool_2.1.6.8.exe,

The link of tool:



https://mega.nz/file/9iQ0gBhb#F3BXI9HM7QpZuQpT9R_5zkftYNgtYIS1BTknBcamxM8

2. If the interface is Chinese, you can switch languages from here; Open the USB_Burning_Tool, Click on “界面语言” and switch the tool language to English.




3. Then click File-->Import image, choose the firmware(You can use the firmware we provide or your compiling image file)

PS: In the future, if necessary, we can provide the Firmware (burning package) for tool burning.



4. Press and hold the power button, connect your PC and the box through the usb-cable(OTG), then power it on. Please hold the button for 5-10 seconds, until appear Connect success in the tool, see the pictures below:



5. Click Start, when finish the burning, click Stop, and reboot the box.

