

Kloud Note

User Manual

Contents

1. Product view.....3

2. Home.....5

3. Note.....6

4. Reader.....16

1. Product view

Front



Top



Bottom



Function introduction of the buttons

Power/ Sleep-Wake up	● Press the power button to turn on the device ● Press and hold the power button for 2-3 seconds, and select "Power off" in the menu to turn off the device. ● Press the power button and then release it immediately, the device goes to the sleep state ● Press the power button and then release it immediately to wake up from sleep mode
TF Card	● Support 64G (optional)
Type-C	● Connect Kloud Note to PC via Type-C data cable to transfer data, or charge the device
Speaker	● Used for external sound

2. Home

In the lower left corner of home displays the current basic status of the device, including: Mobile / WiFi connection, Bluetooth status and battery display.

Above the device status is the function bar, including: Note, Reader, APPs, Account info.



3. Note

Click on the main interface to display the note list and note management menu.

Search

Search for notes, keywords support note name, note content, note creation time.

New folder

After creating a new folder, you can move notes to the folder.

Display mode

Click to switch the display mode of notes: grid or list.





Sort

It can be sorted in ascending/descending order of note creation time, note modification time, and note name.



Long press the note, you can choose to rename, export, lock/unlock, move

or delete the note.



Long press the folder, you can choose to rename, move, or delete the folder.



Cloud-sync

(Login account is required) You can synchronize notes to cloud storage. Each time you log in to your account, it will automatically synchronize notes from cloud storage to the device.

Settings

You can set note related settings, such as: Show/don't show template setting when creating notes, turn on/off kloudnote automatic synchronization function, binding third-party cloud disk account, backup and recovery management.

3.1 Handwriting

Click "New" to create a new blank note, and click on any note cover to enter the note handwriting page.



Pages

You can quickly view the contents of all pages of the current notebook in card mode. Click ⋮ in the card to pop up the menu of adding new page, clearing current page and deleting current page.



Undo / Redo

Can quickly undo or restore the undone handwriting.

Pen

Adjust the stroke size of the ballpoint pen.



Geometry

Click to select different shapes and adjust different line widths.



Eraser

Can choose free erasing, area erasing, erasing all, and deleting the current page.

Disable / Enable touch

Disable/Enable hand touch operation.After disabling hand touch, the device can only be operated with a pen.

Recording

Click the button to start recording, and click again to stop it, and a recording icon

will be generated in the page after saving.

Show/Hide recording menu



List of recordings

Click to display the recording list, and play, sort, rename and delete the recording files.



More

Click to bring up the hidden menu.

Export

The available note export methods are: Export current page in PDF, Export all in PDF, Export current page in PNG.

You can choose whether to export to local or to a third-party network disk with a bound account.

Note, If the account is not bound, it can only be exported to the internal storage of the device.



Type of writing paper

Different type of writing paper can be selected/switched.



Full screen / Exit full screen

Go to full screen / exit full screen mode.

4. Reader

Click on the main interface to display the book list and the book management menu.

Search

Local search for books, keywords support book title, author, annotation, and the first two lines of the bookmark page.

Search for books online, keywords support book titles and authors.

New bookshelf

After creating a new bookshelf, you can move other books and documents to the bookshelf.

Display mode

Click to switch the display mode of books: grid or list.


10:16
2023/04/29 Sat
yoyo
751.2MB/1000.0MB
25.1 GB/32 GB
Note
13 Notes 3 Folders
Reader
11 Books 1 Folders
APPS
1/2
PDF
3%
User_Manual
This manual mainly provides help for kloud note users. It contains 12 parts, including product overview, home page, notes, reader, application, settings, product ...
Last read: 2021/09/10 10:15:14
Reference
MOBI
NEW
The Power of Habit
FB2
NEW
THE BEST ALTERNATE HISTORY STORIES OF THE 20TH CENTURY
The Best Alternate History Stories of ...
RTF
NEW
PIERGIORGIONICOLAZZZINI
EPUB
NEW
NOTHING TO ENVY
Ordinary Lives in North Korea
Barbara Demick
Nothing to Envy
TXT
NEW
Lord of the Flies
DOC
NEW
Ediable forest Gardens
HTML
NEW
E Ink - Wikipedia
PDF
NEW
AN4397-Common Hardware Design



Scan

Click it to scan all documents in the internal storage and display them in the default bookshelf.

The supported formats are: PDF, TXT, EPUB, MOBI, RTF, FB2, DOC, HTML, etc.

WiFi Transfer

When the mobile phone or computer and Kloud Note are connected to the same local area network, you can transfer books and documents from the

mobile phone or computer to Kloud Note via wifi, and they will be added to the default bookshelf after successful reception.



Cloud-sync

(Login account required) You can synchronize books and notes to cloud storage. Each time you log in to your account, it will automatically synchronize books and notes from cloud storage to the device.

Settings

You can set reader related settings, such as: Turn on/off kloudnote automatic

synchronization function, binding third-party cloud disk account, backup and recovery management.



Long press the bookshelf, you can choose to rename, move or delete the bookshelf:

Long press the book, you can choose to lock/unlock, rename, move or delete the book:

4.1 Shortcut menu for reading

Click on the cover of any book to enter the reading interface. The default is to display the reading area in full screen, and display the reading progress, time and battery power at the bottom.


Chapter 1 - Holding Hands in the Dark

North Korea faded to black in the early 1990s. With the collapse of the Soviet Union, which had propped up its old Communist ally with cheap fuel oil, North Korea's creakily inefficient economy collapsed. Power stations rusted into ruin. The lights went out. Hungry people scaled utility poles to pilfer bits of copper wire to swap for food. When the sun drops low in the sky, the landscape fades to gray and the squat little houses are swallowed up by the night. Entire villages vanish into the dusk. Even in parts of the showcase capital of Pyongyang, you can stroll down the middle of a main street at night without being able to see the buildings on either side.

When outsiders stare into the void that is today's North Korea, they think of remote villages of Africa or Southeast Asia where the civilizing hand of electricity has not yet reached. But North Korea is not an undeveloped country; it is a country that has fallen out of the developed world. You can see the evidence of what once was and what has been lost dangling overhead alongside any major North Korean road—the skeletal wires of the rusted electrical grid that once covered the entire country.

North Koreans beyond middle age remember well when they had more electricity (and for that matter food) than their pro-American

1.07% 11:55

Tap the left (vertical) area of the screen to switch to the previous page.

Tap the right (vertical) area of the screen to switch to the next page.

Click the middle (vertical) area of the screen to bring up the menu bar.

The top menu includes: return, enable/disable handwriting, show/hide handwritten notes, search, add/cancel bookmark, turn pages automatically,

refresh, share, settings.

The bottom menu includes: previous chapter, progress adjustment, next chapter, contents, bookmarks, format/display, annotations and notes.



Add / Cancel bookmark

Can add bookmarks. When the bookmarked page is displayed, it will be displayed as an icon for canceling bookmarks, click to cancel bookmark.

Turn pages automatically

When you want to turn the page automatically at a constant speed, you can

 click this icon to turn it on. The page turning interval can be set freely.



Refresh

Refresh the current page completely.

Settings

You can set reading related properties here, such as: Show/hide chapter name, reading progress/time/power, global properties of format, etc.



Previous Chapter / Next Chapter

Can quickly switch to the previous or next chapter, or drag the progress bar in the middle to quickly change the progress.

4.2 Contents

When reading a document, tap the middle of the screen to bring up the menu bar, and tap "Contents" in the lower left corner to view contents.

Click each category to jump to the main text of the page.



4.3 Bookmarks

When reading a document, click in the middle of the screen, and in the pop-up menu bar, click at the top to add a bookmark to the current page. If a bookmark has been added, you can click to cancel.

Bookmarks can be viewed uniformly on the Bookmarks page, which is convenient for positioning and jumping. Bookmarks can be deleted on this interface.

Click each bookmark to jump directly to the body of the page.